

The Basics

Make sure the goods received are the goods that were ordered. Once material is removed from its packaging and cut, it is no longer returnable. Another Ombre, Hombre is printed to order, subsequent dye lots may have a subtle shade variance.

Install 3 drops of wallcovering and assess the installation, if any exist, please stop immediately and call us at 646-374-8040. Labor claims and charges will not be considered under any circumstances. Please make sure that the wallcovering is installed in adequate and final lighting situations. Hang all wallcovering in sequential order as marked on their packaging.

In Situ

Wallcovering must be stored in a climate controlled environment which is consistent with normal living conditions. Temperatures inside should not be below 65F or above 85F, humidity should be relative.

Wall Preparation

Wall preparation is essential, we recommend hanging over a new, smooth sheetrock that is dust free. Most installation issues arise from inadequate wall preparation. If the installation is to occur on a wall which recently had an old wallcovering removed, it is imperative that an experienced contractor is hired to decalcify and properly prep the wall!

Wallcovering Specific Primer | Adhesive

A High quality primer and adhesive is crucial; a latex pigmented wallcovering specific primer is a must. Allow the primer to dry completely before recoating or hanging. We recommend a heavy duty clear strippable adhesive

Glue On Seams | Glue On Face Of Material

Sometimes we get to have do-overs, this isn't one of those times. Our wallcoverings are made from natural materials, they do not perform like vinyl. It is imperative that adhesive does not get on the materials face when installing, it can discolor the material. We recommend that a low adhesive release tape is applied at the edge of the wallcovering and is removed once the panel is in place and set. This will inhibit adhesive from discoloring the seam.

Cleaning

Always take care while cleaning, do not scrub or use abrasive cleaners. Use water and blot the affected area with a clean soft rag. Blot dry with a clean, dry cloth. Do not scrub the material, it can discolor the face.

HANGING DIRECTIONS

JEAN MICHELLE BASGOUCHE

Jean Michelle Basgouche is a four (4) panel mural with a maximum height of 10 feet. Cut the strips to the correct proportion in relation to the size of the wall being mindful of the pattern repeat. After 4 drops the pattern will repeat itself again. Using a commercial heavy duty clear adhesive, roll the backside of the wallcovering giving it time to relax. Jean Michelle Basgouche is designed to be straight hung. Use a soft plastic smoother to lay the panels onto the wall. Butt seem on the pattern match. Do not allow adhesive to get onto the face of the wallcovering. If this happens remove the adhesive immediately when still wet with a damp sponge and dry the surface with a clean, dry towel. Do not use excessive adhesive on this material. Once the adhesive is dried in, it will be difficult to remove. **Always use a fresh blade for every cut and remember, measure twice and cut once.**

